


**ULINE** H-9818  
**BUG FAN**

1-800-295-5510  
uline.com



## SAFETY

 **NOTE:** This product is powered by a 48" USB cable (included) or two AA batteries (not included).


 **NOTE:** The soft-touch fan blades are designed to drive away bugs.

- Children should be supervised when using this product to prevent injury.
- Unplug the USB cable when not in use and before cleaning or repairing.
- To keep the plastic enclosure clean, wipe with a dry cloth.

**ULINE** H-9818

**VENTILADOR REPELENTE  
DE INSECTOS**

800-295-5510  
uline.mx



**SEGURIDAD**



**NOTA:** Este producto funciona con un cable USB de 48" (incluido) o dos baterías AA (no incluidas).




**NOTA:** Las aspas del ventilador suaves al tacto están diseñadas para repeler los insectos.

- Debe supervisar los niños al usar este producto para evitar lesiones.
- Desenchufe el cable USB cuando no lo use o antes de limpiar o reparar.
- Para mantener la cubierta de plástico limpia, límpiela con un trapo seco.

**ULINE H-9818**  
**VENTILATEUR**  
**ANTI-MOUCHES**

1-800-295-5510  
uline.ca



## SÉCURITÉ



**REMARQUE :** Ce produit est alimenté par un câble USB de 48 po (inclus) ou par deux piles AA (non incluses).



**REMARQUE :** Les pales de ventilateur au toucher doux sont faites pour chasser les insectes.

- Les enfants doivent être surveillés lors de l'utilisation de ce produit pour éviter tout risque de blessure.
- Débranchez le câble USB lorsque l'appareil n'est pas en usage, et avant le nettoyage ou la réparation.
- Pour maintenir la propreté du boîtier en plastique, essuyez-le avec un linge sec.