


ULINE

SINGLE WING EASEL BACK


1-800-295-5510
uline.com

Para Español, vea página 2.
Pour le français, consulter la page 3.




INSTRUCTIONS


1. With adhesive strip on board face up, fold side flap backward at the seam. (See Figure 1)




3. Peel backing from adhesive strip on easel. (See Figure 3)




2. Fold top of insert down and lock into tab. (See Figure 2)




4. Attach media to adhesive strip. (See Figure 4)




**INSTRUCCIONES**


1. Doble la solapa lateral hacia atrás en la unión con las tiras adhesivas en la tabla hacia arriba. (Vea Diagrama 1)




2. Doble la parte superior del inserto hacia abajo y asegúrela en la pestaña. (Vea Diagrama 2)




3. Retire el respaldo de la tira adhesiva del caballete. (Vea Diagrama 3)



4. Fije el material a la tira adhesiva. (Vea Diagrama 4)






INSTRUCTIONS


1. Placez la bande adhésive sur le panneau face vers le haut, puis pliez le rabat latéral vers l'arrière au niveau du pli. (Voir Figure 1)

Figure 1




2. Pliez le haut du rabat vers le bas et insérez-le dans la languette. (Voir Figure 2)

Figure 2



3. Décollez la doublure de la bande adhésive du chevalet. (Voir Figure 3)

Figure 3



4. Fixez l'affiche sur la bande adhésive. (Voir Figure 4)

Figure 4

