
ULINE S-7071

SELF-SEAL MULTI-DEPTH MAILER

HOLDS 1-4 CDS


1-800-295-5510
uline.com



ASSEMBLY


1. Lay mailer flat with white side facing down. Place product on center panel. (See Figure 1)

Figure 1




2. Determine height needed. Fold A panels over product at desired height scores. (See Figure 2)

Figure 2




3. Fold B panel over A panels at same height score used for A panels. (See Figure 3)

Figure 3



4. Remove liner from adhesive strip on C panel. (See Figure 4)

Figure 4



5. Fold C panel over B panel at same height score used for A and B Panels. Press down on edge of C panel to secure adhesive strip to B panel. (See Figure 5)

Figure 5

