



ULINE H-814

HIGH TENSILE PUSHER TOOL

1-800-295-5510
uline.com

Para Español, vea páginas 3-4.
Pour le français, consulter les pages 5-6.



ULINE H-814



HIGH TENSILE PUSHER TOOL

1-800-295-5510
uline.com

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Roll Pin	1	H-814-014809	014809
2	Drive Pawl	1	H-814-017959	017959
3	Drive Pawl Spring	1	H-814-017946	017946
4	Tension Handle	1	H-814-306148	306148
5	Pawl Pin	1	H-814-PAWLPN	017945
6	Pinion Gear	1	H-814-GEAR	017925
7	Tension Gear	1	H-814-017926	017926
8	Bushing	1	H-814-017929	017929
9	Feedwheel Shaft	1	-----	017947
10	Button Head Cap Screw – #10-24 x 3/8"	1	-----	041912
11	3/16" SAE Washer	1	-----	184501
12	Button Head Cap Screw – 5/16"-24 x 1/2"	1	H-814-043982	043982
13	SAE Washer 5/16"	1	H-738-WASH	004959
14	Hold Pawl	1	H-814-017943	017943
15	Gear Housing	1	-----	306147
16	Hold Pawl Spring	2	H-814-017944	017944
17	Pivot Pin	1	H-814-017937	017937
18	Feedwheel	1	H-814-020517	020517
19	Lift Arm	1	H-814-ARM	017941
20	Strap Guide Pin	1	-----	001656
21	Breaker Nose	1	H-814-NOSE	017935
22	Socket Head Cap Screw – 1/4"-28 x 3/4"	2	-----	007878
23	Roll Pin – 1/4" x 7/8"	1	H-814-097526	097526
24	Wear Plug	1	H-814-017939	017939
25	Lock Wire	1	H-814-LOCK	017952
26	Base Spring	1	H-814-017942	017942
27	Danger Sign	1	-----	003133
28	Base	1	H-814-BASE	306149
29	Bushing	1	H-814-424035	424035
30	Set Screw	1	H-814-020694	020694

ULINE H-814
HERRAMIENTA DE
EMPUJE DE ALTA
RESISTENCIA

800-295-5510
 uline.mx



ULINE H-814



HERRAMIENTA DE EMPUJE DE ALTA RESISTENCIA

800-295-5510
uline.mx

#	DESCRIPCIÓN	CANT.	NO. DE PARTE DE ULINE	NO. DE PARTE DEL FABRICANTE
1	Pasador del Rodillo	1	H-814-014809	014809
2	Seguro Impulsor	1	H-814-017959	017959
3	Resorte del Seguro Impulsor	1	H-814-017946	017946
4	Mango de Tensión	1	H-814-306148	306148
5	Pasador del Seguro	1	H-814-PAWLPN	017945
6	Engranaje de Piñón	1	H-814-GEAR	017925
7	Engranaje de Tensión	1	H-814-017926	017926
8	Buje	1	H-814-017929	017929
9	Eje de la Rueda de Alimentación	1	-----	017947
10	Tornillo de Cabeza Redondeada de #10-24 x 3/8"	1	-----	041912
11	Rondana de 3/16" SAE	1	-----	184501
12	Tornillo de Cabeza Redondeada de 5/16"-24 x 1/2"	1	H-814-043982	043982
13	Rondana de 5/16" SAE	1	H-738-WASH	004959
14	Seguro de Retención	1	H-814-017943	017943
15	Carcasa del Engranaje	1	-----	306147
16	Resorte del Seguro de Retención	2	H-814-017944	017944
17	Pasador Giratorio	1	H-814-017937	017937
18	Rueda de Alimentación	1	H-814-020517	020517
19	Brazo de Levantamiento	1	H-814-ARM	017941
20	Pasador Guía de la Correa	1	-----	001656
21	Punta del Freno	1	H-814-NOSE	017935
22	Tornillo de Cabeza Ranurada de 1/4"-28 x 3/4"	2	-----	007878
23	Pasador del Rodillo de 1/4" x 7/8"	1	H-814-097526	097526
24	Conector de Desgaste	1	H-814-017939	017939
25	Alambre de Cierre	1	H-814-LOCK	017952
26	Resorte de la Base	1	H-814-017942	017942
27	Letrero de Peligro	1	-----	003133
28	Base	1	H-814-BASE	306149
29	Buje	1	H-814-424035	424035
30	Tornillo de Ajuste	1	H-814-020694	020694

ULINE H-814
OUTIL DE TYPE
POUSOIR HAUTE
RÉSISTANCE

1 800 295-5510
 uline.ca



#	DESCRIPTION	QTÉ	RÉF. ULINÉ	RÉF. DE FABRICATION
1	Goupille cylindrique	1	H-814-014809	014809
2	Cliquet d'entraînement	1	H-814-017959	017959
3	Ressort du cliquet d'entraînement	1	H-814-017946	017946
4	Poignée de tension	1	H-814-306148	306148
5	Broche de cliquet	1	H-814-PAWLPN	017945
6	Engrenage à pignons	1	H-814-GEAR	017925
7	Engrenage de tension	1	H-814-017926	017926
8	Bague	1	H-814-017929	017929
9	Arbre de roue d'alimentation	1	-----	017947
10	Vis d'assemblage à tête ronde de n° 10-24 po x 3/8 po	1	-----	041912
11	Sae Rondelle de 3/16 po	1	-----	184501
12	Vis d'assemblage à tête ronde de 5/16 po -24 x 1/2 po	1	H-814-043982	043982
13	Sae Rondelle de 5/16 po	1	H-738-WASH	004959
14	Cliquet de retenue	1	H-814-017943	017943
15	Boîtier à engrenages	1	-----	306147
16	Ressort à cliquet de retenue	2	H-814-017944	017944
17	Axe d'articulation	1	H-814-017937	017937
18	Roue d'alimentation	1	H-814-020517	020517
19	Bras de levage	1	H-814-ARM	017941
20	Cheville guide de sangle	1	-----	001656
21	Nez	1	H-814-NOSE	017935
22	Vis d'assemblage à six pans creux de 1/4 po-28 x 3/4 po	2	-----	007878
23	Goupille cylindrique de 1/4 po x 7/8 po	1	H-814-097526	097526
24	Bouchon d'usure	1	H-814-017939	017939
25	Fil de verrouillage	1	H-814-LOCK	017952
26	Ressort de base	1	H-814-017942	017942
27	Affichette de mise en garde	1	-----	003133
28	Base	1	H-814-BASE	306149
29	Bague	1	H-814-424035	424035
30	Vis de réglage	1	H-814-020694	020694