


1-800-295-5510 uline.com



TROUBLESHOOTING

OPERATING ISSUE	POSSIBLE CAUSE
No power.	A fuse may be blown or the circuit breaker tripped.
	Plug not fully inserted into the wall outlet.
Internal temperature not cold enough.	Temperature setting is too warm.
	Door is not shut properly or is opened excessively.
	Recently added a large quantity of warm food to the cabinet.
	Close proximity to heat source or direct sunlight.
	Ambient temperature or humidity is very high.
Appliance runs continuously.	Temperature setting is too cold.
	Door is not shut properly or is opened excessively.
	Recently added a large quantity of warm food to the cabinet.
	Close proximity to heat source or direct sunlight.
	Ambient temperature or humidity is very high.