


ULINE H-12144

4-PLY DIGITAL INFLATOR GUN

WITH DIGITAL PRESSURE GAUGE

1-800-295-5510
uline.com




TROUBLESHOOTING

OPERATING ISSUE	CAUSES	RECOMMENDATIONS
LCD display reads <i>b-L0</i> .	Battery power is low.	Replace batteries. Battery cover is located at the rear of the pressure gauge.
LCD display has no reading.	Batteries are dead.	Replace batteries.

ULINE H-12144
**PISTOLA PARA INFLAR
DIGITAL DE 4 CAPAS**
CON MANÓMETRO DIGITAL

800-295-5510
uline.mx




SOLUCIÓN DE PROBLEMAS

PROBLEMA DE FUNCIONAMIENTO	CAUSAS	RECOMENDACIONES
La pantalla LCD muestra <i>b-L0</i> .	La carga de la batería está baja.	Cambie las baterías. La cubierta de las baterías se ubica en la parte posterior del manómetro.
La pantalla LCD no muestra ninguna lectura.	Las baterías están descargadas.	Cambie las baterías.

ULINE H-12144
**PISTOLET GONFLEUR
NUMÉRIQUE POUR
SACS À 4 ÉPAISSEURS**
AVEC MANOMÈTRE NUMÉRIQUE

1 800 295-5510
uline.ca



DÉPANNAGE

PROBLÈME	CAUSES	RECOMMANDATIONS
L'écran ACL affiche <i>b-L0.</i>	Les piles sont faibles.	Changez les piles. Le couvercle du compartiment à piles est situé à l'arrière du manomètre.
L'écran ACL n'affiche rien.	Les piles sont à plat.	Changez les piles.