


ULINE H-1585, H-1950 TOUCH FREE DISPENSER

1-800-295-5510
uline.com




TROUBLESHOOTING

OPERATING ISSUE	RECOMMENDATIONS
No dispense. Motor does not run.	Hands are not directly beneath sensor. No refill is loaded. Incorrect refill is loaded. Batteries are not loaded, or are loaded incorrectly.
No dispense. Motor runs.	Refill is empty or is loaded improperly. Refill pump is not primed.

ULINE H-1585, H-1950

**DESPACHADOR
MANOS LIBRES**

800-295-5510
uline.mx



SOLUCIÓN DE PROBLEMAS


PROBLEMA DE FUNCIONAMIENTO	RECOMENDACIONES
No despacha. El motor no funciona.	Las manos no están justo debajo del sensor. El repuesto no está cargado. El repuesto cargado no es el adecuado. No tiene baterías o están mal colocadas.
No despacha. El motor funciona.	El repuesto está vacío o cargado incorrectamente. La bomba de repuesto no está preparada.

ULINE H-1585, H-1950

**DISTRIBUTEUR
SANS CONTACT**

1 800 295-5510

uline.ca



DÉPANNAGE

PROBLÈME	RECOMMANDATIONS
Ne distribue pas. Le moteur ne tourne pas.	Les mains ne sont pas directement sous le capteur. Aucune recharge n'est installée. Une recharge inappropriée est installée. Les piles ne sont pas chargées, ou ne sont pas bien insérées.
Ne distribue pas. Le moteur tourne.	La recharge est vide ou n'est pas bien installée. La pompe de la recharge n'est pas amorcée.